



Operation guide

NYK SYSTEMS

Installation Instructions

1. Log on to Windows with in an account with the administrator rights.
2. Please close them if there are other running applications.
3. When a **RebroViewer** installation media is put into the optical drive on a PC, the installer starts automatically. Note: If the installer does not start, browse through the installation media with Explorer and execute "RebroViewerInstaller.exe".
4. The necessary software (Microsoft Visual C++ 2015–2022 Redistributable Package) will be installed to start **RebroViewer**.
Note: In the user account control dialog, please select "allow to make changes".
5. Confirm the license agreement that appears and if you agree, select "I accept the terms in the license agreement" to left-click [Next].
Follow the on-screen instructions for installation.
6. When you start **RebroViewer** after completion of installation, the latest version will be checked on the Internet. If the latest version exists, a web updater will start.
Note: Select "allow to make changes" in the user account control dialog. Also, please allow communications for "RebroViewerUp.exe" if your security software interrupts Internet connections.

Uninstallation Instructions

Start [Start Menu]–[Control Panel]–[Program]–[Programs and Features].
Select [**RebroViewer**] and left-click [Uninstall].

Note: The setting file for each user remains on the computer so that it can be used even if RebroViewer is reinstalled. Delete the folders below when deleting the setting.

C: %User%(Login user name)%AppData%Local%NYK Systems%RebroViewer_EN LocalData



System requirements

OS: Microsoft Windows 11, Windows 10 (Supports 64bit)
Graphics boards: :Graphic board or onboard chip that DirectX12 or DirectX9 operates comfortably
Display resolution: 1280×1024 (800) dots per inch or more
Internet connection environments: Required (for the web update)

-
- RebroViewer** is a free redistributable viewer.
 - Always use the latest version of **RebroViewer**. If you use an older "Viewer" version than the "Rebro" on which the drawing was created, the "Viewer" may not correctly show the newly added functions to "Rebro".
 - No individual support for **RebroViewer** is available.

1. Open a drawing

Open a Rebro drawing file.



Memo

From [Open from cloud], you can select the following cloud storage services to open drawing files.

- Box
- Autodesk Construction Cloud
- Catenda Hub
- Dropbox

A screenshot of the 'Open from cloud' dialog box. The 'Open from cloud' button from the toolbar is highlighted with a red rectangle and a white arrow points to the dialog box. The dialog box shows a 'Cloud Selection' list with four options: 'box Box', 'ACC Autodesk Construction Cloud', 'Catenda Hub', and 'Dropbox'. A 'Cancel' button is at the bottom right.

2. Set up the displays

How to enlarge, reduce, or move screens

-Enlarge or reduce

You can enlarge or reduce a screen by rotating a wheel around the mouse position.

-Enlarge a specified area

Right-drag the area where you want to enlarge.

Note: Press End key to revert to the previous display area.

-Move a screen


Press ↑ ↓ ← → keys.

Drag a wheel to move a screen.

Also, drag scroll bars that are placed on the right or bottom on a screen to move a screen.

-Show entirely


Left-click [Fitting of indication area] button on the status bar, or press Home key.




How to change a background color

You can select a background color either white or black.

① Left-click [Setting].




② To show the background in black, checkmark [Indication]-[Brightness of color]-"Show printing paper in black".




How to switch between layer displays

You can switch between Indication/Non-indication for each layer.




①Left-click [List of layers].

②Select the layout or view to switch between Indication/Non-indication.




③Left-click [Indicate] icon to change the settings.
 Indication
 Non-indication

④Left-click [OK].




Memo
 You can filter by entering characters contained in the layer name.

Also, you can operate it on the panel.




How to set up an automatic hidden line

If an automatic hidden line is set for the drawing that you want to open, the setting is reflected.




You can check or change the setting of automatic hidden line by [Automatic hidden line]-[Setting of automatic hidden line].



- Supplementary explanation

In the case that [Process hidden-line manually] is set for the drawing:




The hidden line process was performed but the automatic hidden line is in the OFF state.

When you apply an automatic hidden line to the drawing for which hand operated hidden line was set, Rebro changes the setting details to automatic hidden line. If you want to recheck the state of hand operated hidden line, open the drawing again.


3. Check a drawing

How to measure a distance or an angle


You can determine a distance and coordinate values between the two specified points.



①Left-click [Distance].




For [Distance]



The distance between two specified points appears in the result field.

For [Coordinate value]



The coordinate values and the distance between two specified points appear in the result field.

How to measure the area

Measure the area by specifying vertices.

①Left-click [Area].

The ninth point

The sixth point

The seventh point

The eighth point

The eleventh point

The fifth point

The second point

The first point

The third point

The fourth point

The twelfth point

②Specify all vertices to left-click [Decision] on the context menu(right click).

③The measurement result appears on the ribbon.

How to check the floor height

You can check the floor height set in a drawing.


①Left-click [Setting of floor].

②The table of floor names and floor heights can be checked.

Floor name	Floor height	Z-coordinate value
RFL		19000
5FL	3800	15200
4FL	3800	11400
3FL	3800	7600
2FL	3800	3800
1FL	3800	0
GL	450	-450


As for zoom panels

You can enlarge an area around a mouse pointer on a drawing.





As for property panels

You can check attributes of an element.




As for around-view

You can show the chosen elements from another direction.



③ An around-view in the specified direction appears.








You can switch the viewpoints in around-view.

You can rotate the around-view with the triangles that rotate to the axial direction or with the rotating arrows in the upper-left and upper-right.


Specify the direction to show. Left-click "Angle appointment", you can specify any azimuth and elevation angles.

You can change the viewpoint based on the azimuth set in [azimuth angle of reference]. It is automatically set according to the viewpoint of the view from which the element was selected when starting the around view.

	<p>Left-click a pipette button and choose a line on the drawing to change the viewpoint according to the line angle.</p>
	<p>Switch around-view to CG display.</p>
	<p>Change transparency of CG display in around-view.</p>
	<p>Switch the expression of around-view.</p> <p>[Display or hide of element]: You can set up display or hide for each element type, and settings of CG transparency for around-view.</p> <p>[Display additionally]: You can switch display or hide for elements Only in a view or Across all floor plane-view.</p> <p>[Additional line]: You can switch display or hide for Indication of the grid, Grid line, Floor line, or Origin.</p> <p>[Single line/Double line]: You can switch between single-lines and double-lines in around-view.</p>
	<p>Switch the automatic hidden line between on and off.</p>
	<p>In the ON state, right-drag a mouse to turn the around-view. Choosing an element allows you to turn the around-view around the chosen element.</p>


	Print the around-view.
	Save the image as an image file. [Save in file]: You can save the images into BMP, JPEG, GIF, TIFF, and PNG image format. [Save in clipboard]: You can paste the images onto Word or Excel. [Send by email]: You can send the saved images by e-mail. Left-click [Setting of email sending point] to enter an email address, subject, and main text. [Setting the resolution]: You can set the resolution for a captured image.
	Display additionally the selected element on the current around-view.
	Hide the selected element on the current around-view.
	Start an around-view in the same state of display.

You can start multiple around-views.




Drawing marker

You can add, edit, delete, etc., markers on the drawing. Shapes can be entered for each marker to annotate the drawing, and comments can be added to write instructions.





[Marker] dialog box appears, allowing you to enter shapes on the drawing, as well as marker titles, descriptions, and comments. When you switch to [Target, Action] tab and add target elements of the marker, Rebro can also rubber-display target elements of the selected marker.



Room specification

When you open a drawing with room specifications set, Rebro can show a list of information about the rooms in the drawing and the equipment placed in the rooms.



Filter the contents displayed in the list by floor/room.



Specify the sort order of the list.

Switch the classification.

Group	Floor name	Room name	Ceiling height of ...	Room area	Room volume	Equipment num...	Model number	Name	Number of unit
1FL	1FL	Electric room	4950	21.45	106.18	CUB-1	900W×800L×(16...	Cubicle indoor typ...	1
						CUB-2	900W×800L×(16...	Cubicle indoor typ...	1
						CUB-3	900W×800L×(16...	Cubicle indoor typ...	1
						CUB-4	900W×800L×(16...	Cubicle indoor typ...	1
						CUB-5	900W×800L×160...	Cubicle indoor typ...	1
1FL	1FL	Corridor	2500	30.55	76.37	PAC-1	45 type	4 direction casset...	2

Smoke control compartment

When you open a drawing in which a smoke control compartment has been set, you can check the smoke exhaust air volume and the effective opening area of the installed smoke inlet/outlets.




Room name	Compartment name	Adjacent compartment	Smoke control compartment		Smoke inlet/outlet selection					Smoke inlet/outlet			
			Synchronous opening compartment	Reference room	Area [m ²]	Air volume [m ³ /h]	Install	Air velocity [m/s]	Effective area [m ²]	Opening ratio	Smoke inlet/outlet size	Install count	Effective area [m ²]
Unsat group													
2FL	Room1	Room2	Room3	Room1	4.00	300	Do	10	0.007	0.58	300x300	1 pts	0.052
	Room2	Room1, Room3		Room2	4.00	300	Do	10	0.007	0.58	300x300	1 pts	0.052
	Room3	Room2, Room4	Room1	Room3	4.00	300	Do	10	0.007	0.58	300x300	1 pts	0.052
	Room4	Room3		Room4	4.00	300	Do	10	0.007	0.58	300x300	1 pts	0.052
1FL	Room5	Room6		Room5	8.00	500	Do	10	0.014	0.58	300x300	1 pts	0.052
	Room6	Room5, Room7		Room6	4.00	300	Do	10	0.007	0.58	300x300	1 pts	0.052
	Room7	Room6		Room7	4.00	300	Do	10	0.007	0.58	300x300	1 pts	0.052


The selected compartment can be displayed as a flash indication.

Progress management

When you open a drawing with a construction date (date) set as custom properties, Rebro can color-code and show it before the reference date or after; or before the period, during, or after.



Decide on [Period] or [Slider range] to be checked in progress control. When you left-click [Set range from drawing values], Rebro gets the date set in [Item] on the whole drawing; and sets again the minimum value to the slider's start date and the maximum value to the end value.



In [Date], enter a date that will be the reference for progress management. When you turn on [Color-coded with progress management], all elements are color-coded according to the specified date. Checkmark [Update automatically] and move a slider to update the date and the color-coding on the drawing automatically.

Elements on the drawing are color-coded based on progress control settings.

If [Today] is unchecked, you can enter a reference date for progress management in [Date].

When you turn on [Color-coded with progress management], Rebro enables [Confirmation mode]-[Progress management] and color-codes the elements. ※See also page 16 for "Confirmation mode".




If you checkmark [Update automatically], Rebro automatically updates the color-coding of a confirmation mode on the drawing when progress management settings are changed. If you uncheck it, the color-coding in the confirmation mode on the drawing will be updated when you press [Update].

As you move the slider, the date is updated and the color-coding is also updated.

As for confirmation mode


In the case that System management, Room, Custom property, etc. are set, you can left-click [Confirmation mode] to color-code and show drawings or CGs.





For Color-coding, Custom property, Zone type, etc., confirm at "▼" next to the "Confirmation mode" icon.

To exit a confirmation mode and return to the original colors, left-click [Confirmation mode]-[Exit confirmation mode].

Confirm system management







Color coding	
■	Supply air/Duct
■	Supply air/Elbow
■	Supply air/Air terminal
■	Outside air/Duct
■	Outside air/Elbow
■	Outside air/Air terminal
■	Return air/Duct







Each line of routes that is set for the element will have a color.

Confirm each floor





Elements will be colored for each reference floor.

Confirm each room




Each room that is set will have a color.

Confirm custom property





Select the property. The display is color-coded for each description of the property.

You can confirm a table of values and colors that are set for the property.





The element for which you set custom properties will be colored.

Confirm each zone







Select one in the types you set. Each type will be color-coded.

You can confirm a table of names and colors that are set for the zone.







Elements will be colored in each zone.

Confirm control area of board






The element for which the control area is set will be colored.

Check fire/smoke compartment



You can color fire/smoke compartments, penetration of fire protection compartments, routes on penetration parts, and dampers.

Confirm progress management



Elements of the selected item in progress management are colored.

Elements are color-coded and shown according to the settings on a [Progress management] panel. Left-click a rectangle in the area where the color is shown to change the color.

A screenshot of the 'Progress management' panel. It shows a color selection palette with 'Normal', 'Colorful(1)', and 'Colorful(2)' options. Below the palette, there are fields for 'Item', 'Construction date', 'Date', 'Period', and 'Color'. The 'Color' field is set to 'Before the period' (blue). A mouse cursor is pointing at the blue color swatch.

How to detect clashes

You can confirm the clash detection results by opening the drawing for which Rebro detected clashes.

Left-click [Detect clash] to open [Clash detection] panel.

Balloons of the appropriate color appear at the points of clash or lack of separation. Left-click the clash number on the panel to change the balloon color with the same number.

[Clash detection] panel


On the drawing, switch between balloon shapes, or Indication/Hide for the points of clash or lack of separation.

NO.	Element name	Element name	Contents	X	Y	Z	The quantity of clashes (upper)	The quantity of clashes (lower)
1	City gas Pipe 80A	Beam 350x700H	Lack of Separation	X1+350	Y2+1725	1FL+4139		
2	City gas Pipe 80A	Floor 150H	Clash	X1+394	Y2+1733	2FL+0	1723	150
3	Smoke control D...	Smoke control D...	Clash	X2-2810	Y2+3049	1FL+3870	284	284
4	Smoke control D...	Smoke control D...	Clash	X2-2810	Y2+2668	1FL+3864	378	378
5	Smoke control D...	Smoke control D...	Clash	X2-2604	Y2+2843	1FL+3732	263	263
6	Smoke control D...	Smoke control D...	Clash	X2-2525	Y2+2644	1FL+3942	419	419
7	Smoke control D...	Smoke control D...	Clash	X2-2525	Y2+3056	1FL+3658	412	412
8	Cooling water (ret...	Fitting for pipe fab...	Clash	X2-1793	Y3-1513	1FL+2149	38	2
9	Cooling water (su...	Floor 150H	Clash	X3-951	Y3-851	2FL+0	1304	151
10	Expansion pipe (a...	Floor 150H	Clash	X3-970	Y3-1498	2FL+0	1373	151
11	Cooling water (su...	Floor 150H	Clash	X3-951	Y3-1101	2FL+0	1240	151
12	Cool and warm w...	Floor 150H	Clash	X3-651	Y3-1549	2FL+0	1264	151
13	Cooling water (ret...	Floor 150H	Clash	X3-951	Y3-699	2FL+0	1304	151
14	Cooling water (ret...	Beam 350x700H	Lack of Separation	X3-1000	Y3-400	1FL+4348		
15	Cooling water (ret...	Floor 150H	Clash	X3-951	Y3-449	2FL+0	1304	151
16	Cool and warm w...	Beam 350x700H	Lack of Separation	X3-400	Y3-1500	1FL+4368		
17	Cool and warm w...	Floor 150H	Clash	X3-351	Y3-1451	2FL+0	1264	151
18	Thick conduit pip...	Floor 150H	Clash	X4-2169	Y2+490	2FL+0	1646	151
19	Cable rack 400x70	Floor 150H	Clash	X4-2195	Y3-1540	2FL+0	1331	151

Left-click the list to check the quantity of clashes at the clash points.


RebroViewer

When you double left-click the table or balloon, CG screen appears and brings the viewpoint close to the clash point.





How to search for characters and so on




By entering keywords, you can search for characters, parts and so forth on the drawing.



Narrow down keywords for property descriptions.




If you select the part from the search results, you can confirm the part on a drawing, around-view, or CG.




Memo

Left-click [How to show] to select whether to display or hide CG or around-view, when you select a search result list.





How to capture images


You can save a specified area on Rebro screen as an image.



[Save in file]: You can save the images into BMP, JPEG, GIF, TIFF, and PNG image formats. Also, you can save into PDF file format.
[Save in clipboard]: You can paste the images onto Word or Excel.
[Send by email]: You can send the saved images by e-mail. Left-click [Setting] to enter an email address, subject, and main text.



4.CG






As for mouse actions

Wheel	Go forward or backward by rotating. Move the screen by dragging.
Left-drag	Turn the screen up, down, left, and right around the current position.
Right-drag	Rotate the screen around the position (on the element) where the mouse points.
Double left-click (sweeping)	Bring the viewpoint closer to the specified element.
Double right-click	Make the screen level.

Note: If you rotate the wheel while pressing Ctrl, the screen moves at twice the distance.


How to operate screens on a CG console panel

Forward or backward	Move the viewpoint forward or backward.
Turn to the left or turn to the right	Turn the viewpoint to the left or right.
Turn upward or turn downward	Turn the viewpoint upward or downward.
Slider handle 	Adjust the speed and quantity of movement when moving on the screen.
Move	Specify a moving distance. Set the distance at a pitch of one-click for moving forward or backward.
Pan (Up) or (Down)	Move the viewpoint up or down at the input value.
Pan (Left) or (Right) 	Move the viewpoint to the left or right.
Height	Select the floor name and enter the viewpoint height directly to move the screen.
Fix height	Checkmark in the box, to fix the current height and move the screen forward, backward, left, or right.



As for Property


You can check the information of a specified element by opening its property.




Select mode

If you left-click [] to turn on element select mode, you can select elements in the CG by left-clicking just as you would in the view. An element selected in the view will be displayed in the selected color.

When you select an element, dimension lines and size annotation text will be temporarily displayed.




When you are in element select mode, the context menu items are narrowed down and the element remains selected even when you open its property.



As for layers

On CG screens, you can set up Indication/Non-indication layers and layers transparency.



Left-click [Show] icon to switch the settings.

- Indication
- Non-indication


[Transparency] can be changed by left-clicking the icon.

As the white ratio increases, the transparency increases.




When Non-indication is left-clicked, the transparency icon will be .

When you left-click [Transparency], you can switch between [Normal indication], [Semitransparency], or [Non-indication] for the layer that is set to semitransparent in [List of layers].



As for a movie


You can play movies created with Rebro, or [CG movie output] output with [Clash detection].




As for Scenes

You can register the currently shown CG screen as Scene, and fill out with characters, dimension lines, or figures on it by using [Annotation] tab.

The registered Scene can be printed, saved, and also passed to Rebro.




Comments on Scene can be exchanged in [Comment] tab. You can also pass the data to Rebro, if you save or read in BCF, you can pass it to other CAD.




Memo

You can register up to 9 different viewpoint directions and contents in one scene from [Viewpoint].




As for apparatus

You can check the position of placed parts on CGs or drawings.



2 The screen moves to the position where you can see the selected parts.





Property Number of unit Hyperlink

[Property]
The property information on the selected parts can be checked.

[Number of unit]
A list for number of units for selected parts appears.

[Hyperlink]
You can access hyperlinks that are set on the equipment.



[CG Parts]

Search target Keyword How to show

Search results 1 cases Clear


4 direction cassettes type building multi-...
45 type

[Layer]Equipment : Air conditioner
1FL+2500 . X3-1800 . Y2-829
Equipment number]PAC-1
[Maker name]

3 The selected parts are displayed in the search panel, and the position of the elements can be confirmed on the drawing with a circle mark and leader line.


As for hyperlinks

On CG, you can refer to the linked files or URLs for the equipment that you set up hyperlinks.








How to cut a cross section

You can cut elements in CG and display the cross section.



How to set up the displays and so on

In [Setting] , you can set up the indications and movements on CG screens.




As for “Drawing mode”

“High-speed quality mode”: Move a screen even in the middle of drawing while keeping the image quality of Quality mode.

“Quality mode”: Move a screen after showing all elements.


“Performance mode”: Move a screen while drawing the screen.



5. Print

How to print

You can print Rebro drawings.



②Select a printer.

③Select the print color and number of copies in [Output setting].
If you uncheck "Change line types or thickness according to the printing scale", Rebro prints the line types and thickness as specified when drawing, without reference to the printing scale. If you check "Fitting grid line mark", grid line marks outside the print area will be printed fitting within the print area.

④Select the paper size and printing orientation in [Paper setting].

⑤Select the enlargement ratio for the drawing in [Print scale].

⑥Left-click [Print].

Select [Change of print area] to return to the drawing and specify the printing size and position with a mouse.

When printing, you can change the line thickness for each scale in [Pen setting]-[Thickness] tab.

When printing, you can change the print color for each element color in [Color] tab.

Thickn...	Remarks	1/10	1/20	1/30	1/50	1/100	1/200	1/300	1/400	1/500	1/600	1/601 ...
0.01mm	The thin...	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01	0.01
0.05mm		0.05	0.05	0.05	0.05	0.05	0.05	0.05	0.05	0.05	0.05	0.05
0.07mm		0.07	0.07	0.07	0.07	0.07	0.07	0.07	0.07	0.07	0.07	0.07
0.09mm		0.09	0.09	0.09	0.09	0.09	0.09	0.09	0.09	0.09	0.09	0.09
0.10mm		0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1	0.1
0.13mm		0.13	0.13	0.13	0.13	0.13	0.13	0.13	0.13	0.13	0.13	0.13
0.15mm		0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15	0.15
0.18mm		0.18	0.18	0.18	0.18	0.18	0.18	0.18	0.18	0.18	0.18	0.18

Printing line thicknesses per scale

Line thicknesses on the drawing

Colors on the drawing

Printing color

How to print continuously

You can print layouts of multiple Rebro drawings collectively.

① Left-click [Print continuously].

② Select a printer.

③ Select multiple drawing files in [Addition of file]. You can also select drawing files collectively by specifying a folder with [▼] on the right of the tab.

④ Checkmark the layout to print.

⑤ Left-click [Print].

File name	Layout name	Drawing size	Mark	State
<input checked="" type="checkbox"/> Machine room_sample_eng.reb	<input checked="" type="checkbox"/> Layout group 1-Whole ground plan	A1(841mm×594mm)	Mark ⊕	
<input checked="" type="checkbox"/> Machine room_sample_eng.reb	<input type="checkbox"/> Layout group 1-Pipe section plan	A1(841mm×594mm)	Mark ⊕	
<input checked="" type="checkbox"/> Machine room_sample_eng.reb	<input type="checkbox"/> Layout group 1-Duct section plan	A1(841mm×594mm)	Mark ⊕	
<input checked="" type="checkbox"/> Machine room_sample_eng.reb	<input type="checkbox"/> Layout group 1-Unit plot plan	A1(841mm×594mm)	Mark ⊕	
<input checked="" type="checkbox"/> Sanitary5.reb	<input type="checkbox"/> Layout group 1-Ground plan	A1(841mm×594mm)	Mark ⊕	
<input checked="" type="checkbox"/> Sanitary5.reb	<input type="checkbox"/> Layout group 1-4 direction drawing	A1(841mm×594mm)	Mark ⊕	
<input checked="" type="checkbox"/> Sanitary5.reb	<input type="checkbox"/> Layout group 1-Whole ground plan	A1(841mm×594mm)	Mark ⊕	

Software License Agreement for RebroViewer

NYK Systems Inc. (hereinafter referred to as “Company”) shall grant to Customers rights to use software product of the Company (hereinafter referred to as “Software”) only when Customers agree to any and all terms and conditions contained in this “Software License Agreement” (hereinafter referred to as “Agreement”).

The Customer shall be deemed to have agreed to enter into the Agreement by installing the Software upon selection of “I agree to the provisions in the License Agreement” to be displayed in the dialogue representing the Agreement. In case where the Customer acquires the Software for his/her own personal use, the Agreement shall be established between the Customer him/herself and the Company, while in case where the Customer acquires the Software on behalf of any corporation or other legal entity, the Agreement shall be established between such corporation or legal entity and the Company.

Article 1 Grant of Right to Use

1. The customer may install and use the Software in multiple computers.
2. The customer may make and deliver the duplicate copies of the Software. In the case, the customer shall duplicate the Software including the copyright notice of the Company displayed in the Software.

Article 2 Attribution of Rights

Unless expressly provided for in the Agreement, rights in and to the Software (i.e. title, ownership, copyrights and any other intellectual property rights, etc.) shall be owned by the Company. The Software shall be protected by the Copyright Act.

Article 3 Prohibited Matters

The Customer shall acknowledge that the Software has confidential or proprietary information including intangible property rights protected by the Copyright Act and may not commit an act mentioned below:

1. The customer may not use or duplicate the Software beyond the conditions as set forth in the Agreement.
2. The Customer may not alter, translate, reverse-engineer, decompile or disassemble the Software, either in whole or in part.
3. The Customer may not sell or lease the Software to any third party.
4. The Customer may not eliminate, delete or change the display for right of ownership and intangible property rights that are recorded or displayed in the Software.

Article 4 No Warranty

The Company shall offer the Software as it is. The Company shall in no case assume any responsibility with respect to any express or implied warranty including legal defect liability, the Customer’s loss of business interest caused by the Software, any other damage caused by special circumstances, any other damage to data and the like, and liability for compensation, etc., based on claims for damages by any third party against the Customer regarding intangible property rights.

Article 5 Termination of Right to Use

1. The Customer may terminate the right to use the Software at any time.
2. In case where the Customer falls under the conditions mentioned below, right to use the Software shall terminate automatically:
 - (1) In case of breach of the Agreement by the Customer.
 - (2) In case where the customer is granted right to use a different version of the Software.

Article 6 Measures against Termination of Right to Use

In case where the Customer’s right to use the Software terminates, the Customer shall obliterate or destroy the Software and any duplicates of the Software.

Article 7 No User Support

The Company will not respond to any inquiries or questions with respect to the Software.

RebroViewer Operation Guide <March 24, 2025, Version 7>

'Rebro' is a registered trademark of NYK Systems Inc., NYK Systems Inc. own the copyright of 'Rebro' and 'RebroViewer', and other rights relating to the 'Rebro' and 'RebroViewer', Do Not copy, alter all or part of this product regardless of its form.

Windows 11, Windows 10 are registered trademark of Microsoft Corporation in USA and other countries. InfiPoints® is registered trademark of ELSIUM Inc. MITSUMORI KUN® is registered trademark of Comcare Inc. Revit®, Autodesk Construction Cloud® are registered trademark of Autodesk Inc. Box® is registered trademark of Box, Inc. Dropbox® is registered trademark of Dropbox, Inc. Luminous Planner™ is trademark of Panasonic Corporation. DK-BIM is registered trademark of DAIKIN INDUSTRIES, LTD. SPIDERPLUS® is registered trademark of SpiderPlus & Co. CheX® is a registered trademark of YSL Solution CO., LTD. MEL-BIM is registered trademark of Mitsubishi Electric Corporation. GyroEye is registered trademark of informatix Inc. BIMcloud® is registered trademark of GRAPHISOFT SE. BIMXD® is registered trademark of Nexceed Inc. Catenda Hub is registered trademark of Catenda AS. B-LOOP is registered trademark of Izumi CONSULTING Inc. Qrespo® is a registered trademark of Kawamura Electric Inc. ANDPAD® is registered trademark of ANDPAD Inc. Ducter is registered trademark of NEGUROSU DENKO CO., LTD. Other products are trademark or registered trademark of each company. The copyrights of 'BLCJ standard' and 'BE-Bridge' and 'Stem' are owned by BLCJ (Building information modeling Library Collaborative research association of Japan) in Japan. This application incorporates Open Design Alliance software pursuant to a license agreement with Open Design Alliance. Open Design Alliance Copyright (C) 2002-2019 by Open Design Alliance. All rights reserved. This product based on IFC Engine™ from RDF Ltd., VB-Report7 from Advance Software Corp., PDF-XChange PRO SDK from Tracker SoftWare Products, DotNetZip Library from CodePlex, SpreadSheetGear® from XLSOFT under each requirement of redistribution. This product use a patent of SHIMIZU CORPORATION (Japanese patent No.6384709) by permission. This product include parts from TOTO LTD. and LIXIL Corporation, by permission. These parts are added informations to proffered shapes. And down-sized as not change appearance. The contents under the "LPBatch" folder in the installation environment are used under license from Panasonic Corporation.